

Rust & Surface



READ SAFETY INSTRUCTIONS
AND MSDS BEFORE USE

PRODUCT DESCRIPTION

Rusting is the biggest disease for the steel or automotive component industry. Hi-Tech International's proprietary rust converters, help in the recovery of metal by converting the

Instantly Remove
Recover Original



In case of light rusting only on the surface of the component, apply the rust converter preventive and rub it on the rusted surface. It would vanish within 30 seconds of application.

In case the rusting is deep with pitting, follow the described process:

1. Prepare separate water tanks or baths using
 - a. Rust Converter Rr500
 - b. Water
 - b. Neutralizer NN 500
 - c. Rinsing Water
 - d. Rust Preventive 135 E/ CL
2. Put Rust Converter Solution in the tank
3. Dip the metal into the RUST CONVERTER tank.
4. The reaction will start with release of gas bubbles.
5. Keep checking the component for complete conversion of rusting
6. When the rust is converted into metal, take the component out and transfer to tank containing water and rinse thoroughly.
7. Then transfer the component to the neutralizer to de-activate the surface and stop the reaction.
8. After Neutralizing rinse & wash the component with water thoroughly.
8. Take the component out of cleaning tank and apply rust preventive RUST-X 135E oil immediately
by dipping in the rust preventive. This will neutralize the surface, de water the surface, and will form
a rust preventive layer on the surface.

The metallic component is now, as good as NEW.




Rusted Part



Dipped for removal



Rust free after 3 mins.



RUST
from your manufacturing

hi-tech international
W-79 MIDC taloja, maharashtra
29, gat 281/1 kasaramboli, pirangut, pune
b-31 opp power house, chandigarh road, ludhiana
p:0161-3250700, 3260700 f: 2680791

w: www.rustx.net e: info@rustx.net
delhi-maharashtra-chennai-ahmedabad-coimbatore-
jamshedpur-punjab-haryana-j&k-hp-karnataka-mp